

ANTI-GRAVITY SWING, INC.

14250 ROMINE ROAD
CARLETON MI, 48117
1-888-292-1053
1-800-666-4741
1-734-654-2233

NEW ASSEMBLY INSTRUCTIONS...USE OTHER ASSEMBLY INSTRUCTION SHEET FOR REFERENCE ONLY.

TOOLS NEEDED...Phillips screwdriver and 7/16" wrench.

.....

Mount BED on to PIVOT ARMS, using $1\frac{1}{2}$ " bolts...Place wing nut in DOUBLE LOCKING CLIP at bottom of BED.

ADJUSTING RAIL...Remove nut and bolt from REAR ANKLE CLIP. Slide REAR ANKLE BAR through CLIP and secure on to RAIL with nut and bolt...Slide RUBBER ANKLE SUPPORT on to each side of BAR, cut-out facing up. (Lubricate rubber with liquid soap, Ivory, Dove, etc., for easy mounting).

...Slide FOOTBAR through BOTTOM BRACKET ASSEMBLY.
Bolt into place with $1\frac{1}{4}$ " bolt.

Insert assembled ADJUSTING RAIL through DOUBLE LOCKING PIN ASSEMBLY on end of BED and continue through GUIDE CLIP. Rail must go through GUIDE CLIP.

LOCKING HANDLE...Loosen nut and turn FRONT ANKLE BAR sideways. Secure nut...Slide RUBBER ANKLE SUPPORT on to each side of BAR, cut-out facing down. (Lubricate rubber with liquid soap).