
## ASSEMBLY INSTRUCTIONS FOR GRAVITY SWING

## FRAME ASSEMBLY

Ref.

## No. Description

- 1 Front Frame
- 2 Back Frame
- 3 Horizontal Frame Brace
- 4 Vertical Support Bar (2)
- 5 Bearing Bracket Assembly (2)
- 6 Frame Locking Strap (2)



- 1. Bolt BEARING BRACKET ASSEMBLY on to each side of BACK FRAME, as shown (use 11/2" bolts).
- 2. Bolt FRONT FRAME on to BEARING BRACKET ASSEMBLY in same manner.
- 3. Bolt FRAME LOCKING STRAPS to outer sides of FRAME (use 11/4" bolts).

Double Locking

Pin Assembly

- 4. Mount HORIZONTAL BRACE (use 11/4" bolts).
- 5. Bolt two VERTICAL SUPPORT BARS into place.
- 6. Insert ½" x 2" bolt through hole in each BEARING BRACKET ASSEMBLY. Secure with ½" nut on each side. Bolt should protrude on inner side of BEARING BRACKET ASSEMBLY.

4. Attach entire assembly on to BED

placed, as shown.

(use  $1\frac{1}{2}$ " bolts). It is essential that PIVOT ARMS are properly

